

Your Global Automation Partner

TURCK

EZ-track® Q21 Series Quadrature Output

Manual

Chapter 1: Hardware Overview 3

1.1 Dimension Drawing for Q21 Quadrature 4

Chapter 2: Installing the LDT

2.1 Installing the LDT 5

Chapter 3: EZ-track Q21-DQ Overview

3.1 Quadrature Output 6

3.2 Signal Connection Application Note 6

3.3 Quadrature Output Resolution & Speed..... 7

3.4 Q21-DQ Wiring Connection 7

3.5 Features 11

3.6 Q21-DQ..... 12

3.7 Trouble shooting for Q21-DQ..... 13

3.8 Catalog Numbering System for Q21 14

3.9 Accessories 15

3.10 Specifications for Q21-DQ..... 16

Warning:
Disconnect Power Before Servicing. The Q21 Quadrature Contains No Serviceable Components.
Consult Factory for Repair or Replacement.

Chapter 1: Hardware Overview

Overview

The Q21 with Quadrature Output is an accurate, auto-tuning, non-contact, linear displacement transducer in an economical, low profile package. The transducer utilizes our field proven magnetostrictive technology to give absolute position, repeatable to .006% of the sensing distance. The streamlined anodized aluminum extrusion houses the sensing element and electronics. The magnet moves over the sensing element that determines the position and converts it to incremental outputs.

Features

The Q21-DQ LDT has a truly unique feature. This LDT has auto-tuning capability, the ability to sense a magnet other than the standard slide magnet and adjust its signal strength accordingly.

There is an indicator LED that is located at the connector end of the probe and provides visual status information regarding the operation of the probe. Green indicates proper or normal operation. Red indicates the loss of the magnetic signal or a probe failure.

Green: Magnet is present and within the active range.

Red: Fault, the LDT has lost its signal from the magnet or the magnet has moved into the Null or Dead zone.

Yellow: Used when in communication/program mode.

Note:


The part number on your LDT is a record of all the specific characteristics that make up your unit. This includes what interface type it is, its output signal and range, the type of connector the unit uses, and stroke length.

The Q21 with Quadrature Output provides A and B digital output signal that is proportional to the position of the magnet assembly along the length of the LDT. The quadrature output makes it possible to have a direct interface to virtually any incremental encoder input or counter card, eliminating costly absolute encoder converters and special PLC interface modules. A "Z" channel is also provided and its position can be set by the user at any position along the active stroke. The transducer features an input to re-zero the LDT "on the fly". Another unique feature is the "burst" mode. An input on the transducer triggers a data transfer of all the incremental position data relative to the transducer's absolute zero position. This is how the incremental output can provide absolute functionality. The "burst" input can be used to achieve absolute position updates when power is restored to the system or anytime an update is needed to re-zero or home the machine without having to move the machine.

1.1: Dimension Drawing for the Q21 Quadrature

A standard female swivel mounting arm is provided with the slide magnet assembly. For extensions and other options contact TURCK at 800-544-7769.

Mounting Brackets (MB-Q21) slide in the grooves on the side of the extruded housing. When tightened down with fastening hardware the mounting bracket clamps the unit into place. It is recommended to use one mounting bracket on each end and every three feet between.



Note: The North Pole of the magnet should be pointed towards the probe.

Chapter 2: Installing the LDT

Mounting Instructions

The Q21-DQ LDT can be mounted vertically or horizontally using MB-Q21 mounting brackets. The mounting brackets slide in the grooves on the lower part of the extrusion and clamp down when tightened. It is recommended to use one mounting bracket on each end and every three feet in between. Ferro-magnetic material, (material readily magnetized) should be placed no closer than .25" from the sensing surface of the LDT.

Mounting the Magnet Assembly


Before mounting the magnet assembly, you should consider the following:

- Ferromagnetic material should not be placed closer than 0.25 inches from the LDT's sensing surface. Failure to do so could cause erratic operation. Non-ferrous materials, such as brass, copper, aluminum, non-magnetic stainless steel or plastics, can be in direct contact with the magnet assembly and sensing surface without producing any adverse results.
- Make sure that the magnet is located within the LDT's active stroke area. Captive magnet assemblies should be positioned so that they can move freely over the entire area of the active stroke without binding or pushing on the extrusion. Non-captive magnet assemblies should be situated so that the magnet is no further than 3/8" from the sensing surface at any point in the floating magnet assembly's movement.
- When using the Floating Magnet assembly (FM-Q21), the magnet should be installed within .375 inches of the sensing surface. The magnet assembly should also be installed in such a manner that it remains an even distance from the aluminum extrusion throughout the entire stroke. Improperly installed magnets can result in output signal non-linearity.

Chapter 3: EZ-track Q21-DQ Overview

3.1: Quadrature Output

The output from the transducer can be wired directly to any incremental encoder input card, without the need for a special converter module or PLC interface card designed specifically for use with a pulsed output magneto-restrictive transducer.



The quadrature output provides absolute position data in engineering units. This means that the need for the calibration constant (wire speed) programming has been removed, thereby eliminating the possibility of having an improperly calibrated system. The output signal wires are driven by differential line drivers, similar to the drivers used in most pulsed type transducers, providing a high degree of noise immunity.

A unique feature of this transducer is a "burst" mode of operation. An input on the transducer triggers a data transfer of all the incremental position data relative to the transducer's absolute zero position. This can be used to achieve absolute position updates when power is restored to the system or anytime an update is needed to re-zero or home the machine. Additionally, another input to the transducer can be used to establish a "zero" position for the transducer.

3.2: Signal Connection Application Note

Overview

This application note will clarify the input and output signals of the Q21-DQ LDT probe.

Inputs

The quadrature probe has two inputs, the "zero" and "burst" inputs. These inputs are "single ended". That is, the connection for each input consists of only one wire, the corresponding signal wire. For these single ended inputs, the signal is measured with reference to the power supply ground, which is sometimes referred to as "common".

The quadrature probe is available with either +24 VDC level signal thresholds or TTL level thresholds. The signal voltage level required to activate the input for the +24 VDC level signal is approximately 41% of the power supply voltage.

* For example, if the power supply voltage powering the probe is exactly 24VDC, the threshold voltage would be approximately 9.84 volts.

The TTL level threshold signals are activated when these inputs exceed the typical TTL level threshold, which is 2.0 VDC.

Additionally, for the 24 VDC level signals, either a "sourcing" or "sinking" type of input can be specified. A "sourcing" input type is pulled high internal to the probe. To activate a "sourcing" input, the customer must pull the signal lower than the threshold voltage to activate the input. A "sourcing" input is usually driven by a "sinking" output or a switch connected to ground.

A "sinking" input type is pulled low internal to the probe. To activate a "sinking" input, the customer must pull the signal higher than the threshold voltage to activate the input. A "sinking" input is usually driven by a "sourcing" output or a switch connected to the power supply.

It is important that the customer drive the signal levels much greater or lower than the threshold voltages. Asserting a signal with a voltage level close to the threshold voltage could induce multiple activations of that input (or none at all) and therefore produce unexpected results or probe readings.

3.2: Signal Connection Application Note (continued)

Outputs

The quadrature probe has three differential outputs, the "A", "B" and "Z" outputs. These outputs are "differential" (also known as "balanced"). That is, the connection for each output consists of two signal wires. These are typically described as the "+" and "-" signals. For example, the "A" channel consists of "A+" and "A-". The same applies to the B and Z channels. For these (differential) outputs, the signal is measured with reference to the other signal (i.e. the difference or differential). For example, if the "A+" signal voltage is greater than the "A-" signal, channel "A" is a logic "1". Conversely, if the "A+" signal voltage is lower than the "A-" signal, channel "A" is a logic "0". Again, this applies to the B and Z channels as well. Differential type signals are much less prone to interference caused by electrical noise or ground loops more often found in single ended signal connections.

The differential outputs of the A, B and Z channels are at RS-422 signal levels on option "R" output driver units. RS-422 is a well known TIA/EIA standard and common interface type for incremental encoders. The RS-422 receiver channel (on the PLC or controller side of the connection) typically has what is referred to as a termination resistor connected across the "+" and "-" signal pins. The value of the termination resistor is (by RS-422 specifications) typically 100 ohms. For proper signal integrity, especially at higher data rates (i.e. quadrature pulse frequency), a termination resistor of no greater than 1 kΩ is recommended.

Driving Single Ended Inputs

A differential output can also be used to drive single ended inputs. Special consideration must be given to these types of applications. It should be noted the main signal requirements for an RS-422 signal is the differential voltage of the "+" relative to the "-" signals and not necessarily the voltage level of any one of these signals with respect to ground (or common). To meet the RS-422 specification, this differential voltage only needs to be +/- 0.2 volts. However, an RS-422 driver will typically drive either the "+" or "-" signal to around 3.8 volts with respect to ground. This voltage is more than sufficient to drive TTL level inputs as well as other low level inputs. The input voltage level specifications of the PLC or controller being used should be consulted for the actual level required.

When using PLC's or controllers that are not TTL compatible output driver option "L" should be used. Option "L" uses a 0L7272 line driver I.C. The output from this driver will be 1 volt less than the LDT's input power.

When physically connecting a differential output to a single ended input, only use the "+" signal, leaving the "-" signal unconnected. **Do NOT connect the "-" signals to ground.** The "A+", "B+" and "Z+" signals should be connected to their corresponding inputs. Insulate and tie back the "-" signals.

3.3: Quadrature Output Resolution & Speed

The internal resolution of the Q21-DQ LDT is 0.001". This would be represented to the encoder input device by specifying an output resolution of 1,000 cycles per inch for the transducer. Although the typical resolution is 1,000 cycles per inch (CPI), the transducer can be ordered with virtually any CPI setting.

For a typical rotary type shaft encoder with incremental quadrature output, the output frequency of the pulses is governed by the resolution of the encoder (pulses per turn) and the rotational speed (RPM) of the encoder. The output pulse rate from the transducer is stretched out over the LDT internal update time. The output frequency must be specified so that it does not exceed the maximum pulse rate of the encoder input card the sensor is connected to. The output pulse frequency range can be ordered from 1KHz to 1MHz.

3.4: Q21-DQ Wiring Connections

Once the LDT has been installed, wiring connections can be made. There are two groups of connections you will need to make. They are as follows:

- Power Supply Connections (including grounding and shielding)
- LDT Input/Output Connections

Power Supply/Ground Connections

To reduce electrical noise the shield must be properly used. Connect the cable's shield to the controller system GND. The cable shield is not connected at the transducer end. Always observe proper grounding techniques such as single point grounding and isolating high voltage (i.e. 120/240 VAC) from low voltage (10 - 30 VDC cables). Whenever possible, this cable should be run in conduit by itself.

3.4 Q21-DQ Wiring Connection (continued)




Figure 3-1: Power Supply Wiring

Warning:
Do not route the Q21 with Quadrature Output cable near high voltage

Pin 1	White	B+
Pin 2	Brown	+V
Pin 3	Green	Z+
Pin 4	Yellow	Z-
Pin 5	Grey	A+
Pin 6	Pink	A-
Pin 7	Blue	GND
Pin 8	Red	Burst
Pin 9	Orange	Zero
Pin 10	Tan	B-
Pin 11	N/C	-
Pin 12	N/C	-




Figure 3-2: Power Supply Wiring

3.4 Q21-DQ Wiring Connection (continued)







Figure 3-3: Input Signal Connections for Q21 Quadrature LDT

3.4 Q21-DQ Wiring Connection (continued)



Output Connection for Q21-DQ LDT with Differential Interface



Output Connection for Q21-DQ LDT with Single Ended Interface

Figure 3-4: Output Signal Connections for Q21 Quadrature LDT

3.5 Features

Automatic Gain Control

The Automatic Gain Control feature will automatically search and find the magnet on power up, if power is applied without a magnet on the LDT, the LED will turn RED indicating no magnet signal is detected. Turn power off and place magnet within the active stroke area. Re-apply power.

When using the Floating Magnet assembly, the magnet should be installed within 3/8" of the sensing surface. The magnet assembly should also be installed so that it remains an even distance from the aluminum extrusion throughout the entire stroke. Improperly installed magnets can result in output signal non-linearity.

LED Colors	
Green	Magnet is present and within the active programmed range.
Red	Fault, the LDT has lost its signal from the magnet or the magnet has moved inot the Null or Dead zone.
Yellow	Factory use only. Used to determine when the LDT is in the programming mode.

Burst Mode

This feature enables the system to be absolute even though data transfer is through an incremental method. In the event of power failure, the controller can be programmed to automatically send a signal to the probe, which will then respond with the current position data. An input signal to the probe will cause a "Burst" of data, representing the absolute position, to be fed back to the controller.

3.5 Features (continued)

ZERO Pulse

By sending an input signal to the probe at any point in the stroke, a new zero point can be established. When using the burst input, the absolute position provided will be relative to the programmed zero position. In probes with volatile storage the zero point will be kept until a new zero pulse is sent or until the probe loses power. Probes with nonvolatile storage will store the zero position even if you lose power. The nonvolatile zero can be set 100,000 times; the volatile zero can be set an infinite number of times.

3.6 Q21-DQ

Frequency or Pulse Rate

Selecting the proper frequency in the LDT's part number is very important. The Q21-DQ has an internal update time of 1 millisecond on LDT's less than 60" in length and approximately 2 milliseconds on the units greater than 60" in length. The LDT will stretch the amount of pulses travelled over the update rate. All incremental pulses must be transmitted before the LDT will interrogate itself again. The frequency or pulse rate of the Q21-DQ is factory set from 1KHz - 1.00MHz, consult part number for your model. The input for the PLC or display will determine the frequency needed.

Example: If your PLC High Speed counter card or display accepts a 1MHz encoder input, the choices are

A = 10KHz	D = 75KHz	G = 250KHz
B = 25KHz	E = 100KHz	H = 500KHz
C = 50KHz	F = 150KHz	I = 1.00MHz

NOTE:

If your controller's maximum input frequency falls between two available frequencies, choose the lower frequency.

Output Drivers

The Q21-DQ LDT uses a 0L7272 line driver IC. Your LDT was configured at the factory for either a TTL level output or a 10 - 30 VDC level output. Refer to label on LDT for your output type.

R = Differential RS-422 line driver, TTL compatible

L = Differential line driver 10 - 30VDC

V out = V in (LDT Power) -1 volt

Option R has a 5 volt TTL level output regardless of input power.

Option L has an output of 1 volt less than probe input power. This option is used when driving higher voltage input cards and is not TTL compatible.

3.7 Troubleshooting for Q21-DQ

Troubleshooting describes common problems that may occur when installing the LDT and offers possible solutions to these problems. If, after reading this appendix, you are unable to resolve a problem, contact our technical support department at 1-800-544-7769.

General Checks

Make sure that the magnet is located within the LDT's active stroke area. Captive magnet assemblies should be positioned so that they can move freely over the entire area of the active stroke without binding or pushing on the extrusion. Non-captive magnet assemblies should be situated so that the magnet is no further than 3/8" from the sensing surface at any point in the floating magnet assembly's movement.

NOTE:

Ferromagnetic material (material readily magnetized) should be located no closer than 0.25" from the sensing surface of the LDT. This includes mounting brackets, magnet spacers, magnet brackets, and mounting screws. Ferromagnetic material can distort the magnetic field, causing adverse operation or failure of the LDT.

Check all LDT wires for continuity and/or shorts. It is preferable that the cable between the LDT and the interface device be one continuous run. If you are using a junction box, it is highly recommended that the splice junction box be free of AC and/or DC transient-producing lines. The shield should be carried through the splice and terminated at the interface device end.

Power Supply Check

This section will help you to determine if your power supply is adequate for the LDT to operate properly, or if the LDT's cable has a short or open. In order for the Q21-DQ LDT to operate properly, the external power supply must provide a level between 13.5 to 30 VDC. A power supply providing voltage above this specified range may damage the LDT. A power supply providing power below this specified range will not be sufficient to power the LDT. When powering more than one LDT on a single power supply, remember that each LDT requires three (2.5) watts of power maximum (2 watts typical). The amount of current draw will vary based on the input voltage used. To calculate the current draw for a particular LDT, divide the LDT wattage by the input voltage. For example, 2 watts divided by 24 VDC equals 104 mA.

If your LDT is not operating properly, the LDT's cable may have an open or short, or the power supply is not supplying sufficient power. To verify this, perform the following steps:

1. Turn the power supply off.
2. Remove the mating connector from the LDT.
3. Turn the power supply on.
4. Using a digital voltmeter, check from power supply common (GND) and Power Supply + (Vsource) from the mating end of the cable for a level between +13.5 and +30 VDC.

If reading is between 13.5 and 30 VDC, turn power supply off and go to step 7. If reading is below 13.5 VDC, either your power supply is not providing enough power or the LDT's cable possibly has a short/open. Readings of no voltage or minimal voltage (less than 5 volts) may be due to short/open in the cable. If reading is not between 13.5 and 30 VDC, go to step 5. If reading is above 30 VDC, adjust power supply or replace.

5. Turn the power supply off.
6. Check the continuity of the individual wires of the cable between the power supply and the LDT. Check for continuity from one end of the cable to the other. Also verify that no shorts exist between pins.
7. Reconnect the mating connector to the LDT.
8. Turn power supply on.
9. Using a digital voltmeter, check the power supply's "+" and "-" terminals for a voltage between 13.5 and 30 VDC.

Low voltage readings may indicate a power supply with a wattage (current) rating that is too low. (Each LDT requires 2.5 watts). If the cabling checks out in step 6 and your voltage is below 13.5 VDC, check your power supply current rating. If voltage is between 13.5 to 30 VDC and the LDT is still inoperative, contact factory.

3.8 Catalog Numbering System for Quadrature Q21

Part Number Key: Quadrature Profile Series

A	B	C		D		E	F	G	H	I	J		K
LT	40	E	-	Q21	-	DQ	R	A	N	N	X2	-	H11121

A	Type
LT	Linear Transducer

B	Measuring Span
*	Length of Measuring Span

C	Units of Measurement
E	Inches

D	Housing Height
Q21	21 mm
Q35	35 mm

E	Resolution
DQ	Quadrature

F	Output Configuration
L	10-30 VDC, Line Driver
R	13.5 - 30 VDC, RS422 Line Driver (TTL Compatible)

G	Quadrature Cycle Frequency		
A	10 kHz	F	150 kHz
B	25 kHz	G	250 kHz
C	50 kHz	H	500 kHz
D	75 kHz	I	1000 kHz
E	100 kHz		

H	Zero Offset Storage
N	Nonvolatile (100,000 storage cycles max)
V	Volatile


I	Input Type
N	Sinking (Typically used with Sourcing Outputs)
P	Sourcing (Typically used with Sinking Outputs)
T	TTL Level

J	Number of LED's
X2	2 Diagnostic LED's


K	Type of Connection
H11121	12-pin M12 eurofast ® Connector

3.9 Accessories


Slide Magnet
SM-Q21 [A5600]




Slide Magnet with Slide Adapter
SA-Q21 [A0864]




Floating Magnet
FM-Q21 [A5500]




Control Arms
CA*E-Q21




Q21 Upside Down Brackets
UB-Q21 (2/bag) [A5500]



Q21 Mounting Brackets
MB-Q21 [A5700]



Rod Ends
RE-Q21 [A0865]



RBVA-M5

Angle Joint for M5 Thread,
Stainless Steel



ABVA-M5

Angle Joint for M5 Thread,
Stainless Steel



* Length in inches.


3.10 Specifications for Q21-DQ

General Specifications		
Null Zone	3.00"	
Dead Zone	2.00"	
Extrusion Assembly	Anodized Aluminum with gasket seals, IP 67, IP 68 Optional	
Connector	12 Pin, 12mm euromast ® Connector	
Sensor Length	5" to 180"	
Agency Approval	CE	
Shock & Vibration	Random Vibration Shock	MIL-STD 810E, 10Grms random, 20Hz - 2K Hz Tested to 40G

Electrical Specifications		
Input Voltage	Unipolar 13.5 to 30 VDC	
Current Draw	2.5 watts maximum	
Nonlinearity	+/- 0.05% of full stroke	
Repeatability	+/- 0.006% of full stroke	
Hysteresis	+/- 0.02% of full stroke	
Operating Temperature	-20° to 70° C	
Storage Temperature	-40° to 85° C	
Drivers		
Option R	1. Quadrature A 2. Quadrature B 3. Zero (index) position Maximum 5 volts, minimum 2 volts into a 50 ohm load (TTL compatible)	RS-422 differential RS-422 differential RS-422 differential
Option L	1. Quadrature A 2. Quadrature B 3. Zero (index) position Maximum 30 VDC, min 13.5 VDC, driver 0L7272 V out = V in (LDT Power) - 1 volt	differential line driver differential line driver differential line driver
Digital Input	1. Zero position set 2. Burst mode input Input impedance Sink threshold Source threshold TTL threshold	5 - 30 volts Source or Sink 5 - 30 volts Source or Sink 5 K ohms Input < 0.41 * Power Supply Voltage i.e. 0.41 x 24 VDC Power Supply = < 9.84 VDC Input > 0.41 * Power Supply Voltage i.e. 0.41 x 24 VDC Power Supply = > 9.84 VDC Input > 2.1 Volts
Update Time	40" or less 41" to 100" 101" to 150" 151" to 180"	1mS (Stroke Lengths 5" to 40") 2mS (Stroke Lengths 41" to 100") 3mS (Stroke Lengths 101" to 150") 4mS (Stroke Lengths 151" to 180")
Specifications are subject to change and are based on a typical 36" LDT		

Notes:

TURCK



28 subsidiaries and over
60 representations worldwide!

Printed in USA

B1403 A 10/15

©2015 by Turck Inc. All rights reserved. No part of the
publication may be reproduced without written permission.

www.turck.com