

Your Global Automation Partner

TURCK

Devicent Encoder Replacement 5860 to RM-89 Series

Manual




Swapping Kuebler 5860 with RM-89 Device Net Resolver

The following section explains how to replace Kuebler 5860 DeviceNet encoder with RM-89 Resolver. The only common denominator for both devices is the position measurement, which is provided as 32-bit value back to PLC. Other features are or may be different such as:

- IO data size
- Supported parameters
- EDS files

The encoder's replacement and scanner's reconfiguration has to be done online in following steps:

1 Use RSNetworx Tool drop down menu to install RM-89 EDS file:




Follow instructions:




2 Go on-line and upload network content:




Kuebler 5860 encoder is in the scan-list and will be replaced at the same address with the RM-89:




3 Upload scan-list from the scanner:




4 Note the that offset where the Kuebler 5860 encoder has been mapped is "1:I.Data[3]"
Other memory locations are reserved for other nodes:




5 Remove Kuebler 5860 encoder from the scanlist, click “Apply” and download configuration to the scanner:




6 Remove the Kuebler 5860 encoder from the network; set address of the RM-89 to 6 and cycle power to the RM-89. Browse network and click on “≠”:



7 Click **OK** to resolve mismatch:




8 Enter into Name "RM89", click "Apply" and "OK"




9 Click on the scanner and upload scanlist;


- a. Uncheck "Automap on Add"
- b. Click > to enter RM89 into scanlist
- c. Click **Apply**




10 Click on **Input** tab and **Advanced...**




11 Advanced mapping is done exactly as follows:




First 32 bits will be mapped to the scanlist at offset "1:l.Data[3]". Click **Apply** and **Close**:




12 Map RM-89 outputs to unused portion of the IO data map; click **apply** and **download** to the scanner:




13 Double-click on **RM89** and upload parameters; General tab shows device identity:




14 Click on **Parameters**, highlight “Position” parameter:



15 Click on **Monitor**, turn shaft and monitor position:



16 Check PLC reading:



17 Setup other RM-89 parameters using RM-89 User Manual



Turck Inc. sells its products through Authorized Distributors. These distributors provide our customers with technical support, service and local stock. Turck distributors are located nationwide – including all major metropolitan marketing areas.

For Application Assistance or for the location of your nearest Turck distributor, call:
1-800-544-7769

Specifications in this manual are subject to change without notice. Turck also reserves the right to make modifications and makes no guarantee of the accuracy of the information contained herein.

Literature and Media questions or concerns?
Contact Marketing Turck USA – tusa.marketing@turck.com

TURCK



28 subsidiaries and over
60 representations worldwide!

Printed in USA

©2017 by Turck Inc. All rights reserved. No part of the
publication may be reproduced without written permission.

MA1033 A 04/17

www.turck.com