


SOURCE DRAWING - FOR REFERENCE ONLY

INSTRUCTIONS:

1. INSTALL PILOT HOLE IN PANEL OR ENCLOSURE REQUIRING DOUBLE "D" PUNCH.
2. FULLY SEAT DRAW STUD INTO PILOT HOLE AND PUNCH.
3. LUBRICATE THREADS AND ATTACH COUNTER NUT.
4. DIE SHALL FIT OVER DRAW STUD.
- 5 LUBRICATE THREADS AND ATTACH BALL BEARING DRIVE NUT.

RELATED DOCUMENTS 1. 2. 3. 4.	3RD ANGLE PROJECTION		THIS DRAWING IS CONFIDENTIAL AND THE PROPERTY OF TURCK INC. USE OF THIS DOCUMENT WITHOUT WRITTEN PERMISSION IS PROHIBITED.	<div>TURCK</div> <div>3000 CAMPUS DRIVE MINNEAPOLIS, MN 55441 1-800-544-7769 (763) 553-7300 (763) 553-0708 fax www.turck.us</div>			
MATERIAL TOOL STEEL	ALL DIMENSIONS DISPLAYED ON THIS DRAWING ARE FOR REFERENCE ONLY CONTACT TURCK FOR MORE INFORMATION		DRFT	GJA	DATE	09/06/01	DESCRIPTION FK(S)FD-TOOL
FINISH BLACK ANODIZED			APVD		SCALE	1=1	
			UNIT OF MEASUREMENT MILLIMETER [INCH] DO NOT SCALE THIS DRAWING				
			IDENTIFICATION NO. A2550				REV A
			FILE: A2550				SHEET 1 OF 1

A	DRAWING RELEASE	JB	12/12/01	
REV	DESCRIPTION	BY	DATE	ECO. NO.