


# **Dynamic Inclinometer** With Analog Outputs B1NF360V-QR20-2LI2X3-H1151



Туре
ID

B1NF360V-QR20-2LI2X3-H1151			
100030754			

Combination of gyroscopes and accelerometers


#### Measuring principle

General data		
Resolution	16 bit	
Measuring range	0360°	
Number of measuring axes	1	
Repeat accuracy	$\leq$ 0.03 % of full scale	
Linearity deviation	≤ 0.15 %	
Temperature drift	$\leq$ ± 0.006 %/K	
Electrical data		
Operating voltage U <sub>B</sub>	1530 VDC	
Ripple U <sub>ss</sub>	$\leq$ 10 % U <sub>Bmax</sub>	
Isolation test voltage	0.5 kV	
Short-circuit protection	yes	
Wire break/reverse polarity protection	yes/yes	
Output function	5-pin, Analog output	
Current output	420 mA	
Load resistance voltage output	$\ge$ 4.7 k $\Omega$	
Load resistance current output	$\leq$ 0.4 k $\Omega$	
Current consumption	< 80 mA	

-

- Rectangular, plastic, Ultem
- Status displayed via LED .
- Angle detection via one axis with 360 ° measuring range
- High protection class IP68/IP69K
- Protected against salt spray and rapid temperature change
- 15...30 VDC .
- M12 × 1 male connector, 5-pin
- Two counter-running 4...20 mA analog outputs improve machine safety through redundancy
- The start, end and center point of the measuring range can be adjusted using teach adaptor TX1-Q20L60
- Individual parameterization possible with USB-2-IOL-0002

#### Wiring Diagram



Mechanical data	
Design Rectangular, QR20	
Dimensions	71.6 x 62.6 x 20 mm
Housing material	Plastic, Ultem
Electrical connection	Connector, M12 × 1

## **Functional principle**

The dynamic inclinometers use an acceleration measuring cell and a gyroscope sensor to determine angles. Influences caused by vibrations or interfering acceleration are minimized by applying an intelligent fusion algorithm to the acceleration data and the rotation rate values. This enables the sensor to output a robust signal with impressive precision and speed, even in moving, dynamic applications. The robust sensors are positioned with the cast side on a flat surface so that the casting



Environmental conditions		
Ambient temperature	-40+85 °C	
Temperature changes (EN60068-2-14)	-40 +85 °C; 20 cycles	
Vibration resistance (EN 60068-2-6)	20 g; 5 h/axis; 3 axes	
Shock resistance (EN 60068-2-27)	200 g; 4 ms ½ sine	
Protection class	IP68	
	IP69K	
MTTF	297 years acc. to SN 29500 (Ed. 99) 40 °C	
Power-on indication	LED, Green	
Measuring range display	LED, yellow	
UL certificate	E351232	

compound is covered. The sensor is then secured with two screws.

Hans Turck GmbH & Co.KG • D-45472 Mülheim an der Ruhr • Witzlebenstraße 7 • Tel. 0208 4952-0 • Fax 0208 4952-264 • more@turck.com • www.turck.com2 / 4



### Programming instructions

#### Activation of the teach process

	Bridge between pin 5 and pin	LED green	LED yellow
	1		-
Activate teaching	Before switching on the supply	Teach process active:	
	voltage, set the teach bridge,	700 ms/100 ms	
	then switch on the voltage,		
	then remove the bridge imme-		
	diately after starting the sensor		
The teach process is automatic	ally deactivated after 30 s. The y	ellow CENTER LED and the green LE	D flash alternately and then return
to normal operation.			
Teach sequence for center po	int, measuring range start and	lend	
	Bridge between pin 5 and pin 1	LED green	LED yellow
Activate sequence*	Set bridge for 28 s	After 2 s of flashing at 1 Hz	
Set center point**	Bridge for 28 s		After 2 s of flashing at 1 Hz
Set start of measuring range**	Bridge for 814 s		After 8 s of flashing at 2 Hz
Set end of measuring range**	Bridge for 1420 s		After 14 s of flashing at 4 Hz
Factory setting	1	L	
	Bridge between pin 5 and pin	LED green	LED yellow
	1		
Activate sequence for factory settings*	Bridge for 814 s	After 2 s of flashing at 2 Hz	
Reset to factory settings**	Bridge for 28 s		After 2 s of flashing at 1 Hz

\*Teach sequence remains active for 30 s, then returns to normal operation

\*\*After the center point/measuring range/factory settings have been established, the teach sequence ends and automatically returns to the activated teach process



# Accessories

Type code	Ident-No.		Dimension drawing
AP-Q20L60-QR20	100029224	Adapter plate for mounting the QR20 housing with mounting holes for the Q20L60 housing	

## Function accessories

Type code	Ident-No.		Dimension drawing
USB-2-IOL-0002	6825482	IO-Link Master with integrated USB port	LED: CH1 (CQ) CH2 (DVDO) Error 41 M12 × 1 LED: PWR LED: PWR LED: PWR LED: PWR LED: PWR 1N-DC 54 54
TX1-Q20L60	6967114	Teach adapter for inductive encoders, linear position, angle, ultrasonic and capacitive sensors	60 30 20 M12x1 50 M12x1 42.5