


TW-R50-M-K2 HF Tag



Technical data

| etal |
|------|
| etal |
| etal |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| - |



Features

- 3 different mounting options in/on metal, incl. accessories
- FRAM memory 2 kB
- For direct mounting on and in metal

Functional principle

The HF read/write devices operating at a frequency of 13.56 MHz form a transmission zone the size of which (0...500 mm) varies, depending on the combination of read/write head and tag used.

The read/write distances mentioned here only represent standard values measured under laboratory conditions, free from any influences caused by surrounding materials.

The read/write distances of tags suitable for mounting in/on metal were determined in/on metal.

Attainable distances may vary by up to 30 % due to component tolerances, mounting conditions, ambient conditions and material qualities (especially when mounted in metal). Testing of the application under real operating conditions is therefore essential, especially with on-the-fly reading and writing!




Technical data

Protection classIP68Packaging unit1



Mounting instructions/Description



Freimaßtoleranzen: ISO 2768-m

These data carriers can be mounted in 3 different ways:

1. Directly potted or glued in metal (without O-ring)

2. Installed in metal with O-ring (fixed with 2 screws)

3. Mounted upside down on metal (fixed with 2 screws)